

ON/OFF timer

Function of the component

The function component ON/OFF timer is a component, that provides the ON-and OFF time of the interface.

Go to „Controls“ in „Device configuration“. Create a new control function with the green plus

Go to „Functions“ and create a „ON/OFF timer“ component.


At „Name“ enter e.g. blinking light.

At „ON time“ select the turn on time in seconds e.g.: „2“

At „OFF time“ select the turn off time in seconds e.g.: „2“

At „Interface“ enter e.g.: DO_Virtual.

Confirm with „OK“. Then go tot he device configuration and press „Save“.

A screenshot of the "ON/OFF Timer" configuration window. The window has a dark header with the title "ON/OFF Timer". Below the header, there are four rows of configuration options, each with a label, a text input field, and a question mark icon. The first row is "Name:" with an empty text box. The second row is "ON Time:" with a text box containing "2" and the label "Seconds". The third row is "OFF Time:" with a text box containing "2" and the label "Seconds". The fourth row is "Interface:" with a dark button labeled "Select Interface". At the bottom of the window, there are three buttons: "Back" on the left, "no Log" in the center (with a red circle icon), and "OK" on the right.